

## 

Materials				Vc	fz	Harder <> Tougher						
ISO	Mat'l Group #VDI 3323	Туре	Examples	Cutting Speed SFM	Feed/Tooth (inch)	IN2504	IN2505	IN2510	IN2530	IN2035	IN7035	Coolant
Ρ	1 thru 5	Non-alloy Steel	1018, A36, 1045, A572, 1070	400 -1000	.010060		1		2			NO
	6 thru 9	Low-alloy Steel	4140, 4340, P20, 8620, 300M	300-900		2	1		3			
	10, 11	High-alloy Steel	H13, A2, D2, M2, T1	300-650	.010040	2	1		3			
Μ	12 thru 13	"Stainless Steel (Ferritic & Martensitic)"	410, 416, 440	300-650	.010030				3	2	1	YES
	14	Stainless Stee (Austenitic)	"303, 304, 316, 15-5, 17-4"	300-550					3	2	1	
K	15 thru 16	Gray Cast Iron	CLS. 20, 30, 45	400-750	.020040		2	1				NO
	17 thru 20	Nodular Cast Iron	"60-40-18, 100-70-03"				2	1				
S	31 thru 35	High-Temp Alloys	Inconel, Hastelloy, Nimonic, Monel	65-150	0.010030				3	2	1	YES
	36 thru 37	Titanium Alloys	6AL-4V, 5Al-5Mo-5V-3Cr	100-250					3	2	1	
Η	38 thru 39	Hardened Steel >48	A2, 01, D2	160-350	.010-025	1	2					NO

Note: Feed and speed recommendations are starting operating parameters. They are only guidelines from which further optimization should take place. Operating parameters are influenced by many machining variables. These variables may cause for reductions in feeds and speed or dramatic increases. Additionally, DOC and WOC may need to be revised to optimize the tools performance.



